

CAT#	PART#	DESCRIPTION	QTY:	U/M
		<b>SB23 TURBINE</b>		
1, 2	AE023.072N	CASING	1	EA
3	AE080.810N	WHEEL ASSEMBLY 1" blades	1	EA
4	AE068.1285N	SHAFT	1	EA
5	AE017.051N	PACKING BOX	2	EA
6	AC063.107N	CARBON PACKING RING	10	EA
7	AC072.061N	GARTER SPRING	10	EA
8	HP501FZ150	STEAM CHEST DRAIN PLUG	1	EA
9	AC063.102N	RING, SEAL, LABRTH, SB18	2	EA
9A	AC063.104N	O RING FOR LAB.#063/102	2	EA
10	AC043.107N	HOUSING, BEARING, SB18	1	EA
14	AC043.107N	HOUSIN,BEARIN,SB18,	1	EA
15D	AC069.036N	SHIM,BEARING,THRST,L	1	EA
15E	AC069.037N	SHIM ,BEARING,SB-18	1	EA
27	AE011.009N	GOVERNOR LEVER	1	EA
31	AG054.005N	GOVERNOR VALVE STEM NUT	1	EA
32	AG043.007N	GOVERNOR VALVE STEM CRADLE	1	EA
32A	HG001NZ215	GOV STEM CRADLE BOLT	2	EA
33	AG056.001N	GOVERNOR VALVE STEM PACKING	6	EA
34	AG041.004N	STEAM CHEST HEAD	1	EA
34B	AG034.089N	STEAM CHEST HEAD GASKET	1	EA
35	AC043.108N	HOUSING,GOV&TRIP,SB18	1	EA
36	AG072.002N	GOVERNOR VALVE SPRING	1	EA
37	AE074.029N	GOVERNOR VALVE STEM	1	EA
37A	HA135NZ090	GOVERNOR VALVE STEM LOCKING NUT	1	EA
37A	HD13NZ090	HEX NUT EXTERNAL FOR #31	1	EA
38	AG079.008N	GOVERNOR VALVE	1	EA
39	AE024.013N	STEAM CHEST	1	EA
40	AG054.004N	TRIP PLUNGER ADJUSTING NUT	2	EA
42	AG060.002N	TRIP PLUNGER	1	EA
43	AG072.049N	TRIP PLUNGER SPRING	1	EA
44	AC011.044N	TRIP LEVER	1	EA
45	AE027.033N	TRIP LINK	1	EA
46	AG047.001N	TRIP LATCH	1	EA
46A	AG046.001N	TRIP LATCH KEY	1	EA
47	AC040.004N	HANDLE,KNOB ,TRIP STEM	1	EA
48	AG074.001N	TRIP VALVE STEM	1	EA
49	AG054.002N	TRIP VALVE STEM NUT	1	EA
50	AG072.001N	TRIP VALVE SPRING	1	EA
51	AG045.001N	NAME PLATE	1	EA
53	AG079.001N	TRIP VALVE	1	EA
54	AG075.003N	STEAM STRAINER	1	EA
56		MAIN NOZZLE	1	EA

CAT#	PART#	DESCRIPTION	QTY:	U/M
57		MAIN REVERSING NOZZLE	1	EA
58	AE073.021N	AUXILIARY VALVE STAND	1	EA
61		FIRST AUXILIARY NOZZLE	1	EA
62		AUXILIARY REVERSING NOZZLE	1	EA
65	AC063.103N	RING ,SEAL,LABY.SB18	1	EA
65A	AC063.105N	O RING FOR LABY.063/.103	1	EA
67	HD160GZ010	NUT ,LOCK ,N-10,	1	EA
67A	HK024GZ010	WASHER,LOCK ,MRC W10	1	EA
69	AG055.001N	OILER,	1	EA
85	HH099JZ150	TRIP PLUNGER NUT SET SCREW	2	EA
87	HL004JZ096	GOVERNOR VALVE CAGE PIN	1	EA
88	AG021.009N	GOVERNOR VALVE CAGE	1	EA
93	AG021.020N	TRIP VALVE CAGE	1	EA
93B	AG034.088N	TRIP VALVE CAGE GASKET	1	EA
94	HL004JZ062	NOZZLE STAND DOWEL PIN	6	EA
95	AG014.048N	BEARING, BALL, SB18	1	EA
96	AG014.048N	BEARIN,BALL,SB18,	1	EA
99	AG064.001N	TRIP LINK BALL JOINT R.H.	1	EA
99A	AG064.002N	TRIP LINK BALL JOINT L.H.	1	EA
99B	HD148NZ120	TRIP LINK LOCKNUT R.H.	1	EA
99C		TRIP LINK LOCKNUT L.H.	1	EA
101	AE041.006N	GOVERNOR VALVE STEM HEAD	1	EA
110	AC071.077N	SPACER,BRG,SB18,HUB-BRG	1	EA
112	AG079.180N	SENTINEL WARNING VALVE	1	EA
114		SECOND AUXILIARY NOZZLE	1	EA
119	AC029.120N	COVER ,INSPECTION FOR GOV HSG	1	EA
120	AE034.093N	NOZZLESTAND GASKET	3	EA
120	AG034.092N	NOZZLE STAND GASKET	3	EA
127	HR003GZ001	GREASE FITTING	1	EA
128	AG034.087N	AUXILIARY VALVE STAND GASKET	1	EA
130	AG019.043N	TRIP VALVE STEM BUSHING	1	EA
133	AG040.001N	TRIP RESET LEVER	1	EA
135	AG082.001N	TRIP RESET LEVER YOKE	1	EA
144	AG032.007N	BLIND FLANGE	1	EA
145	AG045.002N	ROTATION ARROW	1	EA
147	AE044.015N	TRIP PLUNGER HUB	1	EA
149	AC058.084N	PLATE, END, BALL BEARING, SB	1	EA
151	see order	GOVERNOR	1	EA
154	AE048.004N	GOVERNOR VALVE LEVER	1	EA
154A	AG014.002N	GOV VALVE LEVER BUSHING	1	EA
154B	AG014.003N	GOV VALVE LEVER BUSHING	1	EA
154C	AG057.006N	GOVERNOR LEVER LINK PIN	2	EA
154D	AG057.007N	GOVERNOR LEVER CRADLE PIN	1	EA
155	AG064.003N	ROD END-R.H. THREADS	1	EA
156	AG064.004N	ROD END-L.H. THREADS	1	EA
158	AE034.042N	NOZZLE STAND GASKET SHIM	6	EA
158	AE034.038N	NOZZLE STAND GASKET SHIM	6	EA
160	AG059.003N	HAND VALVE PLUG	2	EA
165	AE011.049N	MANUAL TRIP LEVER	1	EA



